


7 7 7 7 10 10

Step 2 Prepare Wide Mouth

- 2.1 Temporarily hold downspout pipe under and on to the Wide Mouth bottom and mark all four corners [7] where pipe hits Wide Mouth. *Use dimples on Wide Mouth as a guide/reference. Not all downspouts are the same.
- 2.2 Separate pipe and Wide Mouth, then cut all four corners along the bend [8] from bottom [9] of Wide mouth up to your marks [7].
- 2.3 Bend these flaps outward slightly past straight down [10]. Bend along line.

Wide Mouth Outlet (WM) Installation Instructions



Step 4 Final Sealants

- 4.1 Apply sealant over front and back fasteners on inside of the gutter [16].
- 4.2 Apply sealant on the inside of gutter at all four corners **[17]** keep sealant below gutter floor surface.


Wide Mouth Installation is now complete

4.3 - Continue with your connection of downspout piping.

Downspouts pipe needs to be lowered (or cut back) from the gutter floor to allow for the added height of the Wide Mouth Outlet when installed between an existing gutter and downspout pipe.

2''x3'' downspout - lower $\approx 4''$ 3''x4'' downspout - lower $\approx 2''$

Questions? Please contact Raindrop at any time. Phone: 800-816-0199 Email: info@RaindropGutterGuard.com Website (Videos): raindropgutterguard.com/videos



11



www.RaindropGutterGuard.com